GENERAL CLEANING Solutions



- Cleans phones, tablets, laptops and other electronics
- Removes dust, fingerprints and smudges
- Provides a streak-free clean screen





An often overlooked, but necessary part of any facility cleaning and disinfection routine is electronics. Electronics are generally some of, if not the most, utilized and highly touched items in a facility. Because of this, they can become dirty and germ infested quicker than other surfaces in a facility. With State Electronics Cleaner RTU, cleaning your electronics has never been easier. This ready to use product allows for on-the-spot application that requires no mixing or diluting. Simply spray the solution onto a microfiber towel, and wipe the electronics around your facility.

CUSTOM WIPE COMPATIBLE

While you can use this as a spray, we highly recommend running this through our State Custom Wipes™ system. With no more than one quart of product, you can create your very own cleaning wipe. This system does not oversaturate the wipes, as to not damage electronics.

APPLICATIONS

State Electronics Cleaner RTU can be used on a variety of electronics including:

Computers Keyboards
Phones Tablets
Controllers Televisions*
Kiosks And more!

*This product may not suitable for LCD and Plasma screens. Refer to your equipment manufacturer's cleaning instructions.

DIRECTIONS FOR USE:

Follow device manufacturer recommendations when cleaning electronics.

To clean electronics, spray State Electronics Cleaner RTU on a clean cloth, preferably microfiber, then wipe onto surface. Do not spray State Electronics Cleaner RTU directly onto electronics.

State Electronics Cleaner RTU is compatible with the State Custom Wipes. When making as a wipe, make sure to wear all proper Personal Protective Equipment (PPE) before and during handling, and wash hands after handling.

FOR ONE GALLON CANISTER

Remove the lid of the State Custom Wipes canister. Place a roll of wipes in the canister. Wearing proper PPE, pour one full quart of product evenly over the top of the wipes. Once poured, reach inside the canister to the middle of the roll of wipes through the hole in the center of the lid. Press the flap down firmly to close.

FOR SMALL CANISTER

Remove the lid of the State Custom Wipes canister. Place a roll of wipes in the canister. Wearing proper PPE, pour 1/3 of a quart of product evenly over the top of the wipes. Once poured, reach inside the canister to the middle of the roll of wipes through the hole in the center of the lid. Press the flap down firmly to close.

TECHNICAL DATA

APPEARANCE: colorless liquid

ODOR: alcohol TYPICAL pH: 8-9 DENSITY: 8.4 lbs/gal

SHELF LIFE: at least two years

PACKAGING

128904 1 QT Bottle/CS12 128903 1 QT Bottle



State Industrial Products 5915 Landerbrook Drive Mayfield Heights, OH 44124 To Order Call: 1-866-747-2229 www.stateindustrial.com Canada 6935 Davand Drive Mississauga, Ontario L5T 1L5 To Order Call: 1-800-668-6513 Puerto Rico Royal Industrial Park, Bldg "M" Local #5, Carr 869, km 1.5 Palmas Cataño, P.R. 00962 To Order Call: 787-275-3185





